

# JENSEN APP MANUAL



## GETTING STARTED

Download **Jensen Adjustable** to your iPhone 4S, 5, 5S from Appstore or to your Android phone from Google Play. Launch the application by clicking on the icon on your display. (The phone must be connected to Bluetooth LE (Bluetooth 4.0) and have iOS 6.0 or at least Android Kitkat 4.4.3 installed.)

Wait a few seconds for the app to find your bed (which needs to be plugged in and switched on). When the bed is found you can activate it by clicking on the button, which will light up when your bed is connected. *If you have more than one Jensen Adjustable Bed, you can switch between connected beds with reference to guideline 6 below.*



## FUNCTIONS

1. Operate your adjustable bed
  - A. Raise or lower the head and foot section by holding the arrow keys until the desired position is reached. Reset with -button.
2. Alarm function
  - B. Turn on/off alarm, set the desired time and wake up sound or choose a preset program by scrolling up or down. Make your own program under (5).
3. Massage function (applies Aqtive III or Dynamique)
  - C. Head, wave or foot massage. Set the desired intensity and time.
4. Fan function and lamp (lamp only applies to Dynamique)
  - D. Set the desired intensity and time.
5. Program
  - E. Set and save your own program by scrolling (P1-P3), or select one of the preset programs (P4-P5).
6. Bluetooth/Connection
  - F. Switch between the connected beds.

